


RESOL, SOLAR SETTINGS PURE ENERGY (MODEL BS/4) V1.0 8-Feb-08

Adjustment keys



**Model BS/4.
Pump Speed
Control Version**



To View the Readings such as Solar Collector Temperature.

Press & Release '+' button to scroll down, Press & Release button '-' to scroll up

To View the Settings.

Press & Hold '+' button for 2 seconds. To Scroll Down, Press & Release '+' button, '-' to Scroll up.

To Change the set value that is displayed.

(NOTE: Do NOT change any Settings unless advised to do so by a Professional)

Press 'OK' button until the "SET" word on the display flashes, now press + or - button to change the value. Press SET again to save and exit set mode.

SETTINGS

(N/A means that there is no settable value here, E.G. Collector Temperature is just a readout value.)

SETTING NAME	FUNCTION	RANGE	SETTING VALUE
COL	Collector Temperature, Information only, No Setting	N/A	Information Readout
TST	Temperature Store(Cylinder) , Information only, No Setting	N/A	Information Readout
n %	Current pump speed	30-100%	Information Readout
HP	Operating Hours, Information only, No Setting	N/A	Information Readout
ARR	Arrangement	1-2	1
DT 0	Switch-ON, Temperature Difference	1.0-20.0 °C	4.5 °C
DT F	Switch-OFF, Temperature Difference	0.5- 19.5 °C	2.5 °C
DT S	Nominal Temperature Difference	1.5-30.0 °C	5.0 °C
RIS	Raise	1.0-20.0 °C	1.0 °C
SMX	Maximum Store Temperature	2.0-95.0 °C	85°C
EM	Limit Collector Temperature	110 °C- 200°C	170 °C
OCX	System Cooling Option	On/Off	ON
CMX	Maximum Collector Temperature	100-190 °C	140 °C
OCN	Minimum Collector Temperature	On -Off	Off
OCF	Antifreeze Function	On -Off	Off
OREC	Option Re-cooling	On-Off	On
OTC	Tube Collector Special	On-Off	On
OHQM	Heat Quantity Balancing	On -Off	Off
nMN	Pump Speed Control	30 - 100	30
HND1	Solar Pump Control	On/Off/Auto	AUTO
HND2	2 nd Relay Output (Not Used)	On/Off/Auto	AUTO
LANG	Language		EN
PROG	Program No	N/A	69.30
VERS	Program Version	N/A	1.05

Y:\Marketing & Sales\Marketing\Web Marketing\Website\Download Links Etc\Product Brochures\Technical manuals\solar thermal\unsorted\SOLAR CONTROLLER RESOL Model BS4 SETTINGS V0.0.doc

- The control unit records the temp differential between the collector temp and the cylinder temp, and compares that differential with start-up temp differential "DT 0". The solar circuit pump is started if that value is exceeded, and the display shows "(I)". The pump will be switched off if the actual temp falls below the shutdown temp differential "DT F".